

คู่มือการใช้งาน
เครื่องตีฟองนม MiniMEX
รุ่น MMix1-BL



25 W, 220-230 V, 50 Hz

ข้อควรระวังที่สำคัญ

1. ตรวจสอบว่าแรงดันไฟฟ้าที่ระบุบนเครื่องตรงกับแรงดันไฟฟ้าในบ้านก่อนเสียบปลั๊ก
2. ห้ามใช้งานหากสายไฟ ปลั๊ก หรือชิ้นส่วนอื่นชำรุดเสียหาย
3. หากสายไฟชำรุด หยุดใช้งาน ติดต่อศูนย์บริการเบอร์โทร 02-493-6565
4. ถอดปลั๊กทุกครั้งเมื่อไม่ใช้งาน และทุกครั้งก่อนประกอบอุปกรณ์ ถอดชิ้นส่วนหรือทำความสะอาด
5. ห้ามจุ่ม หรือแช่ชุดมอเตอร์ลงในน้ำหรือของเหลวใดๆ ให้ใช้ผ้าสะอาดชุบน้ำบิดหมาดเช็ดทำความสะอาดเท่านั้น
6. ห้ามแยกชิ้นส่วนเครื่อง เนื่องจากไม่มีชิ้นส่วนภายในที่ผู้ใช้สามารถซ่อมแซมได้เอง
7. ห้ามเปิดเครื่องทิ้งไว้โดยไม่มีผู้ดูแล
8. ปิดเครื่องและถอดปลั๊กก่อนสัมผัสชิ้นส่วนที่กำลังเคลื่อนไหว
9. เครื่องนี้ออกแบบมาสำหรับใช้งานในครัวเรือนเท่านั้น
10. เครื่องนี้ไม่เหมาะสำหรับผู้ที่มีความบกพร่องทางร่างกาย ประสาทสัมผัส หรือสติปัญญา รวมถึงเด็ก ยกเว้นได้รับการดูแลหรือคำแนะนำจากผู้ใหญ่ หรือผู้รับผิดชอบ
11. ห้ามเด็กใช้งาน เล่นเครื่องนี้
12. ห้ามใช้งานหากใบพัดหมุนชำรุด หรือโค้งงอ
13. ห้ามสัมผัสใบพัด(หัวผสม)ขณะเสียบปลั๊กอยู่ ใบพัดมีความคม อาจเกิดอันตรายได้
14. หากใบพัด(หัวผสม)ติดขัด ให้ถอดปลั๊กก่อนแล้วจึงนำส่วนผสมที่ขัดอยู่ออก
15. ห้ามใส่ของเหลวมากเกินไป และห้ามเปิดเครื่องต่อเนื่องเกิน 30 วินาที

กรุณาอ่านคู่มือนี้อย่างละเอียดก่อนใช้งานครั้งแรก และเก็บไว้เพื่อใช้อ้างอิงในอนาคต

วิธีการใช้งาน

1. เติมนมลงในถ้วยหรือแก้ว 2-4 ออนซ์ (ประมาณ 60-120 มล.) เพื่อผลลัพธ์ที่ดีที่สุดแนะนำให้ใช้นมเย็นไขมันต่ำ หากต้องการใช้นมปกติหรือนมอุ่นก็ได้เช่นกัน
2. จับเครื่องตีฟองนมแล้ววางปลายหัวตีให้ใกล้กับถ้วยหรือแก้ว เปิดเครื่องแล้วขยับขึ้นลงช้าๆ ขณะนมเริ่มเป็นฟอง ให้ปลายหัวตีอยู่ใต้ผิวนมตลอดเวลา ตีฟองนานประมาณ 25-30 วินาทีหรือจนนมมีปริมาณเพิ่มขึ้นประมาณสองเท่า
3. หากเริ่มต้นด้วยนมเย็น สามารถนำถ้วยหรือแก้วที่ทนไม่โครเวฟได้เข้าไมโครเวฟ 20-30 วินาที เพื่ออุ่นให้ร้อน
4. เดิมกาแฟลงในถ้วย หรือหากใช้แก้ว ให้ช้อนฟองนมลงบนกาแฟ แล้วเพลิดเพลินกับกาแฟสไตล์มีอาซิฟที่บ้าน

การทำความสะอาด

- ล้างปลายหัวตีและแกนด้วยน้ำอุ่น แล้วเช็ดให้แห้งด้วยผ้าสะอาด
- ห้ามจุ่มเครื่องลงในน้ำทั้งหมด และห้ามล้างในเครื่องล้างจาน

การรับประกัน

เครื่องตีฟองนม Minimex รุ่น MMix1-BL ระยะเวลาประกัน 1 ปี

ศูนย์บริการ Minimex:

- โทร. 02-493-6565
- Line OA: @minimex_service
- Email: SERVICE_minimex@penk.co.th

MMix1-BL : HAND FROTHER



25 W, 220-230 V, 50 Hz

IMPORTANT SAFEGUARDS

1. Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance;
2. Do not use the appliance if the mains cord, the plug or other parts are damaged;
3. If the mains cord is damaged, you must have it replaced by the manufacturer, or the service centre authorized by the dealer, or similarly qualified person in order to avoid a hazard;
4. Always unplug the appliance from the mains if it is left unattended and before you assembling, disassembling or cleaning it;
5. Never immerse the motor unit in water or any other liquid, nor rinse it under the tap. Only use a moist cloth to clean the motor unit;
6. Do not disassemble the unit, there are no parts to be serviced by the user in it;
7. Never let the appliance run unattended;
8. Switch off the appliance and disconnect from supply before approaching parts that move in use;
9. This appliance is intended for household use only;
10. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety;
11. Children should be supervised to ensure that they do not play with the appliance;
12. Do not use the appliance if the rotating paddle is damaged or curved;
13. Never touch the blades when the appliance is plugged in. The blades are very sharp;
14. If the blades get stuck, unplug the appliance before you remove the ingredients that block the blades;
15. Do not overload the appliance by putting in too much liquid and do not operate continuously for more than 30 seconds.

Read these instructions for use carefully before you use the appliance for the first time and save them for future reference.

HOW TO USE

1. Fill a cup or beaker with 2-4 oz. of milk. For best results, we recommend starting with cold, nonfat milk. Should you prefer, regular or warm milk will also work.
2. Take the coffee blender and place the tip of the whisk close to the bottom of the cup or beaker. Turn the unit on and slowly move the coffee blender up & down as the milk froths. Keep the tip of the coffee blender below the top of the milk as you froth. Froth for 25-30 seconds or until the volume of milk approximately doubles;
3. If you started with cold milk, you can put the microwave safe cup or beaker into the microwave for 20-30 seconds to heat it up;
4. Add coffee to the cup or, if you used a beaker, spoon the froth onto your coffee and enjoy a professional style coffee drink at home.

CLEANING

- To clean the coffee blender, rinse the metal tip and rod with warm water and wipe dry with a clean cloth.
- Do not submerge the frother or place it in the dishwasher.

WARRANTY

We hereby warranty our Minimex Hand Frother model MMix1-BL in a period of 1 (one) year.

Minimex Service Center

Service Center : Tel. 02-493-6565, LineOA : @minimex_service
E-mail : SERVICE_minimex@penk.co.th