

MINIMEX
PROFESSIONAL



คู่มือการใช้งาน
เครื่องบดเมล็ดกาแฟ

Minimex
รุ่น CG Pro 2-BL

Instruction Manual
Coffee Grinder

Model : CG Pro2-BL

220V., ~50Hz., 300 W.

ไทย / English

คำแนะนำเพื่อความปลอดภัย:

อ่านคู่มืออย่างละเอียด เพื่อความปลอดภัยในการใช้งานและเก็บคู่มือเล่มนี้ไว้

1. ควรอ่านข้อควรระวังต่อไปนี้อย่างละเอียดก่อนใช้งาน
2. ห้ามเครื่องและสายไฟลงในน้ำหรือของเหลว
3. เครื่องบดกาแฟนี้ไม่ควรอนุญาตให้เด็ก ผู้ด้อยความสามารถทางกายภาพ ผู้มีจิตใจไม่สมบูรณ์ และผู้ขาดประสบการณ์การใช้งานอุปกรณ์ไฟฟ้าเหล่านี้เป็นผู้ใช้ ท่านอาจอนุญาตให้บุคคลดังกล่าวใช้อุปกรณ์ได้ภายใต้การดูแลและแนะนำอย่างใกล้ชิด
4. ควรปิดสวิตช์และถอดปลั๊กออกจากเต้าเสียบไฟบ้านทุกครั้งที่ไม่ได้ใช้งาน ขณะถอดหรือใส่อุปกรณ์ และก่อนทำความสะอาด
5. ก่อนใช้งานควรตรวจสอบให้แน่ใจว่า ระบบไฟในตัวเครื่องตรงกับระบบไฟในบ้านของท่าน หากท่านพบว่า เกิดความเสียหายกับตัวเครื่องหรือสายไฟ ซึ่งอาจเกิดจากเครื่องหล่นจากที่สูงหรือเหตุอื่นๆ ควรหยุดใช้งานทันทีแล้วส่งเครื่องเข้าตรวจสอบ ณ ศูนย์บริการฯ
6. ประกอบเครื่องบดกาแฟด้วยอุปกรณ์ที่มีมากับเครื่องเท่านั้น ห้ามใช้อุปกรณ์อื่นร่วมกับเครื่อง เพราะอาจเป็นสาเหตุให้เกิดความเสียหายและอันตรายแก่ผู้ใช้ได้
7. เครื่องบดกาแฟนี้ออกแบบใช้ภายในอาคาร ห้ามนำไปใช้ในที่โล่งแจ้ง
8. อย่าปล่อยให้สายไฟรั้งตรงกับขอบโต๊ะหรือวางใกล้แหล่งความร้อน
9. ควรทำความสะอาดเครื่อง เช่น ฟุ่น หรือเศษผง ก่อนใช้งานทุกครั้ง
10. ตรวจสอบอย่างสม่ำเสมอ เพื่อมิให้วัสดุอื่นเข้าไปในโถใส่เมล็ดกาแฟ
11. ไม่ควรวางเครื่องใกล้เตาแก๊ส เตาไฟฟ้า ที่ใกล้ความร้อน
12. เครื่องบดกาแฟนี้ ออกแบบมาให้ใช้บดกาแฟเท่านั้น หากใช้งานผิดประเภท การรับประกันจะสิ้นสุดลงทันที
13. ระวัง! ในการสัมผัสชิ้นส่วนของเครื่องที่มีการหมุน เช่น เฟืองบด เป็นต้น
14. เครื่องบดนี้ถูกออกแบบมาให้ใช้กับกาแฟเท่านั้น ไม่สามารถบดถั่ว พริก หรือวัตถุดิบอื่นๆ
15. เครื่องบดกาแฟมีการตรวจสอบจากโรงงานโดยใช้กาแฟเมล็ดกาแฟบดจริง ภายในเครื่องอาจมีผงกาแฟหลงเหลืออยู่ อันเป็นสาเหตุมาจากการทดสอบนี้
16. ห้าม! ใส่เมล็ดกาแฟเกินกว่าที่กำหนด
17. ถ้าพบรอยฉีกขาดที่สายไฟควรหยุดใช้และส่งเข้าศูนย์บริการฯ เพื่อทำการเปลี่ยนสายใหม่ทันที
18. ห้ามใช้เครื่องบดกาแฟนี้ เพื่อจุดประสงค์อื่นซึ่งนอกเหนือจากวัตถุประสงค์ในการออกแบบ ในกรณีเช่นนี้การรับประกันจะสิ้นสุดลงทันที
19. เครื่องบดกาแฟทุกเครื่องผ่านการตรวจสอบที่ได้มาตรฐาน

คำเตือน :

- การซ่อมแซมเครื่องโปรดติดต่อศูนย์บริการฯที่เบอร์ 02-493-6565 แผนก MiniMex
- ห้ามแช่ตัวเครื่องลงในน้ำหรือน้ำยาใดๆ หรือใส่ในเครื่องล้างจาน อุปกรณ์ชิ้นเดียวที่สามารถจุ่มลงน้ำคือ โถใส่เม็ดกาแฟที่ถอดออกจากตัวเครื่องแล้ว
- หากเกิดเสียงดัง กลิ่น จากเครื่องในขณะที่ใช้งาน ให้ปิดเครื่องทันที หยุดใช้และส่งเข้าศูนย์บริการฯ

คุณสมบัติสินค้า

รุ่น	CG PRO 2-BL
ขนาดสินค้า	กว้าง 18.5 x ลึก 29.3 x สูง 47.2 ซม.
ความจุโกกาแฟ	550 กรัม
อัตรากำลังไฟ	300 วัตต์
โวลต์	220V/ 50 Hz.

ส่วนประกอบ



- ① ฝาปิด
- ② โถใส่เมล็ดกาแฟ
- ③ แผ่นกันเมล็ดกาแฟ
- ④ ตัวล็อกโถใส่กาแฟ
- ⑤ ระดับเบอร์บดกาแฟ
- ⑥ ตัวเครื่อง
- ⑦ หน้าจอ
- ⑧ ช่องจ่ายกาแฟ
- ⑨ ที่วางก้านชงกาแฟ
- ⑩ ปุ่ม start/stop กดกาแฟ
- ⑪ ปุ่ม on/off สวิตช์หลัก
- ⑫ ปุ่มกันลื่น
- ⑬ ถาดรองเครื่องบดกาแฟ

ปุ่มควบคุม



- 1 แสดงเวลาการบด (วินาที)
- 2 ปุ่มเพิ่มเวลาการบด
- 3 ปุ่มลดเวลาการบด
- 4 ปุ่มบดสำหรับกาแฟ 1 ซีเอส
- 5 ปุ่มบดสำหรับกาแฟ 2 ซีเอส
- 6 ปุ่มบดกาแฟแบบแมนนวล

วิธีถอดใส่เมล็ดกาแฟ

1. ตรวจสอบเครื่องบดกาแฟ ปิดปุ่มสวิตช์/ถอดปลั๊ก เพื่อความปลอดภัย
2. ตรวจสอบไม่ให้มีเมล็ดกาแฟในโถบด
3. หมุนคลายตัวล็อกโถออก ดึงโถเมล็ดกาแฟขึ้น

หมายเหตุ : หากมีเมล็ดกาแฟเหลืออยู่ในโถมาก ให้ดันแผ่นกันเมล็ดกาแฟเข้ากับตัวโถ แล้วค่อยดึงโถขึ้น แผ่นกันเมล็ดกาแฟช่วยลดการกระจายของเมล็ดกาแฟ



วิธีถอดเฟืองบดด้านบน

1. หมุนคลายตัวล็อกโถออก ถึงโถเมล็ดกาแฟขึ้น
2. หมุนระดับเบอร์บดกาแฟทวนเข็มนาฬิกา ยกวงแหวนเบอร์บดออก
3. ยกเฟืองบดด้านบนขึ้น

หมายเหตุ : โปรดใช้ความระมัดระวังขณะยกเฟืองบดด้านบนขึ้น



วิธีถอดที่วางก้านชงกาแฟ และที่รับก้านชงกาแฟ

1. ใช้ประแจคลายสล็อกที่วางก้านชงกาแฟ ท่านสามารถเลื่อนระดับสูง-ต่ำของที่วางก้านชงได้



2. ใช้ประแจคลายสล็อตที่รับก้านชงกาแฟ เพื่อถอดออก



หมายเหตุ : กรณีที่ใช้โถรงรับกาแฟ สามารถถอดที่รับก้านชงกาแฟออกเพื่อใส่โถบดได้

วิธีการใช้เครื่อง

1. ตั้งค่าเบอร์บดกาแฟโดยหมุนวงแหวนระดับการบด เครื่องบดกาแฟมีระดับเบอร์บด 0-100 เบอร์ โดยเบอร์ 0 : บดกาแฟละเอียดสุด เบอร์ 100 : บดกาแฟหยาบสุด



หมายเหตุ :

- การปรับกาแฟให้บดละเอียดขึ้น : ไม่ควรปรับในขณะที่มีเมล็ดกาแฟตกค้างอยู่ หรือท่านสามารถปรับเบอร์บดกาแฟในขณะที่เครื่องทำงานอยู่ได้
- การปรับกาแฟให้บดหยาบขึ้น : สามารถปรับเบอร์บดกาแฟในขณะที่เครื่องทำงานอยู่ได้

2. ใส่เมล็ดกาแฟลงในโถ ไม่ควรเกินปริมาณ MAX ที่กำหนด



3. การตั้งค่าหน้าจอ

- กดปุ่ม **+** : เพิ่มเวลาการบด

- กดปุ่ม **-** : ลดเวลาการบด

- กดปุ่ม **☉** : บดสำหรับกาแฟ 1 ซีต (เอสเปรสโซ่ 1 ซีต)

- กดปุ่ม **☺** : บดสำหรับกาแฟ 2 ซีต (เอสเปรสโซ่ 2 ซีต)

เสียบปลั๊กเครื่องเข้ากับเต้าเสียบไฟบ้าน กดปุ่ม เปิด/ปิด เพื่อเปิดเครื่อง หน้าจอแสดงการทำงาน

การบดสำหรับกาแฟ 1 ซีต (เอสเปรสโซ่ 1 ซีต) : ☉

กดปุ่ม ☉ (กาแฟแก้วเดียว) หน้าจอแสดง 10 วินาที ท่านสามารถกดปุ่ม +/- เพื่อเพิ่มลดเวลาการบด
ใส่ก้านชงกาแฟ ดันก้านชงให้ถูกปุ่ม Start/ Stop เพื่อเริ่มการบด เครื่องจะบดตามเวลาที่ตั้งไว้

การบดสำหรับกาแฟ 2 ซีต (เอสเปรสโซ่ 2 ซีต) : ☺

กดปุ่ม ☺ (กาแฟ 2 แก้ว) หน้าจอแสดง 20 วินาที ท่านสามารถกดปุ่ม +/- เพื่อเพิ่มลดเวลาการบด
ใส่ก้านชงกาแฟ ดันก้านชงให้ถูกปุ่ม Start / Stop เพื่อเริ่มการบด เครื่องจะบดตามเวลาที่ตั้งไว้

หมายเหตุ : เครื่องบดกาแฟจะจำค่าเวลาล่าสุดที่ได้ตั้งไว้โดยอัตโนมัติ

วิธีการใช้เครื่องแมนนวล (Manual Mode)

กดปุ่มบดกาแฟแมนนวล  เป็นเวลา 2 วินาที หน้าจอแสดงสัญลักษณ์

กดปุ่ม Start / Stop เพื่อเริ่มการบด

กดปุ่มบดกาแฟแมนนวล  เพื่อหยุดการบด

กลับสู่การตั้งค่าต้น : กดปุ่ม  ,  พร้อมกันเป็นเวลา 2 วินาที

ปิดเสียง : กดปุ่ม  และ  พร้อมกันเป็นเวลา 2 วินาที

ระบบป้องกันความร้อน

เครื่องบดกาแฟถูกออกแบบมาให้ใช้งานต่อเนื่อง 30 นาที หากหน้าจอแสดง **E2**

ให้หยุดใช้เครื่องเป็นเวลา 10 นาทีหรือจนกว่าเครื่องจะเย็นลง

หมายเหตุ : การใช้งานต่อเนื่อง ควรพักเครื่องอย่างน้อย 10 นาที

ระดับการบดกาแฟ

	เอสเปรสโซ	มือค้ำพอต	ดริป	ฟิวโอเวอร์	เฟรชเพรส
ประเภทเครื่องชงกาแฟ					
ระดับการบด	ละเอียดมาก	ละเอียด	กลาง	หยาบ	หยาบมาก
เบอร์บด	1-15	15-40	40-60	60-80	80-100

หมายเหตุ : การตั้งระดับการบดกาแฟ ควรดูประเภทของกาแฟควบคู่ไปด้วย

ข้อควรระวังเกี่ยวกับเครื่องบดกาแฟ

- หากบดกาแฟและชงทันที จะทำให้กาแฟออกมาหอมอร่อย
- เครื่องบดกาแฟที่ดี นำมาซึ่งรสชาติของกาแฟ การตั้งค่าบดจึงต้องเหมาะสมของเครื่องชงกาแฟประเภทนั้น
- ควรดูวันที่ผลิตกาแฟ ไม่ควรใช้กาแฟที่หมดอายุ หรือเปิดถุงแล้วเกิน 3 เดือน เพราะจะทำให้รสชาติกาแฟลดลง
- เก็บกาแฟในถุงเท่านั้น
- ไม่ควรเก็บเมล็ดกาแฟในกล่องโปร่งแสง
- ใส่เมล็ดกาแฟตามจำนวนที่ใช้ลงในโถ ไม่ควรใส่เมล็ดกาแฟมากเกินไปและค้างทิ้งไว้
- ควรทำความสะอาดเครื่อง โถกาแฟหลังการใช้งานทุกครั้ง
- สามารถล้างโถใส่กาแฟได้ สำหรับเฟืองบด ควรใช้เมล็ดทำความสะอาดเฟืองบดกาแฟ ท่านสามารถติดต่อสอบถามศูนย์บริการได้ที่เบอร์ 02-493-6565

การถอดทำความสะอาดเฟืองบด

เมื่อใช้งานเครื่องบดกาแฟ ท่านสามารถถอดเฟืองบดมาทำความสะอาดด้วยแปรงปัด ดูวิธีการถอดเฟืองบดได้ที่หัวข้อ วิธีถอดเฟืองบดด้านบน



ถอดท่อช่องจ่ายกาแฟออกมา ใช้แปรงปัดเศษกาแฟภายใน



การดูแลรักษา

- ไม่ควรทิ้งเมล็ดกาแฟข้างไว้ในโถใส่กาแฟ เพราะอาจทำให้ความสดใหม่ของเมล็ดหายไป และเกิดน้ำมันกาแฟไหลลงสู่เฟืองบด ทำให้เฟืองบดติดขัดได้
- ถอดปลั๊กไฟหากไม่ได้ใช้งาน
- ห้ามแช่ตัวเครื่อง และสายไฟลงในน้ำ
- โถใส่ผงกาแฟที่ถอดออกจากตัวเครื่องแล้วสามารถล้างทำความสะอาดได้ ห้ามใช้แปรงขัด อาจทำให้เกิดรอย และเสียหายได้
- การถอดเฟืองบด ดึงลวดจับเฟืองด้านบน หมุนและถอดออกในแนวตั้ง
- ใช้แปรงขัดเศษกาแฟ ทำความสะอาดเฟืองบดด้านบน
- ใช้ผ้าสะอาด ชุบน้ำบิดหมาดทำความสะอาดโถกาแฟ
- ใส่เฟืองบดด้านบนเข้ากับเฟืองบดด้านล่าง หมุนตามเข็มนาฬิกาให้ลงล็อก

หมายเหตุ : ระวังอย่าให้มีเมล็ดกาแฟตกค้างขณะการประกอบเฟืองบดและวงแหวนระดับการบด

การถอดทำความสะอาดเฟืองบด

ปัญหา	คำอธิบาย	การแก้ปัญหาเบื้องต้น
เมล็ดกาแฟไม่ลงบด	มีแผ่นกั้นกาแฟ	ดึงแผ่นกั้นกาแฟ เพื่อให้เมล็ดกาแฟลงบด
เครื่องไม่ทำงาน	- ไม่ได้เสียบปลั๊ก - ไม่ได้กดปุ่ม On/Off	เสียบปลั๊กและกดปุ่มเปิด On/Off
	วงแหวนเบอร์บดไม่ลงล็อก	หมุนวงแหวนให้ลงล็อก
	มอเตอร์ไม่ทำงาน	ปิดเครื่อง พักเป็นเวลา 10 นาที

การรับประกัน

เครื่องบดกาแฟ Minimex รุ่น CG Pro 2-BL ระยะเวลาประกัน 1 ปี

เงื่อนไขการรับประกัน

การรับประกันครอบคลุมถึงคุณภาพของสินค้าและมีเงื่อนไขการประกอบโดยสินค้าต้องใช้ในครัวเรือนเท่านั้น ผู้ใช้ต้องใช้งานและบำรุงรักษาอย่างถูกต้องตามคำแนะนำในหนังสือคู่มือ

ข้อยกเว้นการรับประกัน

บริษัทฯ ขอสงวนสิทธิ์ในความรับผิดชอบต่อความเสียหายใดๆ ที่เป็นผลสืบเนื่องจากการใช้สินค้า และสงวนสิทธิ์การรับประกันหากลูกค้า :

- นำสินค้าไปใช้ผิดจากวัตถุประสงค์ของการออกแบบ เช่น การนำเอาสินค้าที่ออกแบบมาเพื่อการใช้ในครัวเรือน แต่นำไปใช้เพื่อประกอบอาชีพหรือในเชิงพาณิชย์
- ใช้งานผิดวิธีหรือไม่ได้ใช้งานตามวิธีที่อธิบายในหนังสือคู่มือ
- มิได้บำรุงรักษาตามคำแนะนำในหนังสือคู่มือ

การใช้สิทธิ์การรับประกันสินค้า

การรับประกันสินค้ามีผลตามวันที่ ที่ระบุในใบรับประกันสินค้า กรุณาแสดงใบรับประกันสินค้า หรือใบกำกับภาษี ใบเสร็จรับเงิน เพื่อเป็นหลักฐานในการติดต่อเจ้าหน้าที่ศูนย์บริการฯ ในการใช้สิทธิ์การรับประกันสินค้า

การพิจารณาความบกพร่องของสินค้าเพื่อการรับประกัน

บริษัทฯ จะทำการตรวจสอบสินค้าอย่างละเอียด และตัดสินใจว่า ความบกพร่องของสินค้านั้นอยู่ในเงื่อนไขการรับประกันหรือไม่ ซึ่งเป็นสิทธิ์ของบริษัทฯ เท่านั้น ในกรณีที่อยู่ในเงื่อนไขการรับประกัน บริษัทฯ จะเป็นผู้รับผิดชอบค่าแรงในการซ่อม ค่าอะไหล่ และค่าจัดส่งสินค้าถึงบ้านลูกค้า โดยลูกค้าไม่ต้องชำระค่าบริการใดๆ ทั้งสิ้น หากบริษัทฯ พิจารณาเห็นว่า ต้องเปลี่ยนสินค้าใหม่ให้แก่ลูกค้าแต่สินค้านั้นเดิมๆ ไม่มีจำหน่ายแล้ว บริษัทฯ จะเป็นผู้ตัดสินใจว่า สินค้ารุ่นใดเหมาะสมที่จะเปลี่ยนแทน

การคืนสินค้า

ในกรณีที่ลูกค้าซื้อสินค้าไปแล้วแต่ไม่ถูกใจ บริษัทฯ ยินดีรับคืนสินค้าภายใน 15 วัน โดยมีเงื่อนไขว่า สินค้าต้องมีบรรจุภัณฑ์อย่างสมบูรณ์และสินค้ามิได้ถูกใช้งานมาก่อน โดยลูกค้าต้องนำหลักฐานการซื้อเพื่อคืนสินค้า ณ ร้านค้าที่ซื้อเท่านั้น

ศูนย์บริการ

หากท่านต้องการบริการรายละเอียดเพิ่มเติมหรือสั่งซื้ออุปกรณ์พิเศษท่านสามารถติดต่อศูนย์บริการได้

Service Center : Tel. 02-493-6565, LineOA : @minimex_service

E-mail : SERVICE_minimex@penk.co.th

ช่วยกันรักษาสิ่งแวดล้อม



เราขอชี้ชวนให้ท่านร่วมรักษาสภาพแวดล้อม
ด้วยการทิ้งเศษอุปกรณ์ที่เลิกใช้แล้ว ณ สถานที่ที่เหมาะสม

MINIMEX
PROFESSIONAL

Instruction Manual
Commercial Coffee Grinder

Minimex

Model : CG Pro 2-BL



Instruction Manual
Commercial Coffee Grinder

Model : CG Pro2-BL

220V., ~50Hz., 300 W.

English

IMPORTANT SAFEGUARDS :

Before operation, please carefully read this Manual and pay attention to the following:

1. In order to ensure safe use and avoid injury and property damage to you and others, please be sure to abide by the following safety precautions. Incorrect use may lead to accidents.
2. Before using this product, read all instructions for use carefully and save for future reference
3. To prevent fire, electric shock and personal injury, do not immerse the cord, plug or body in water or other liquids;
4. This product should not be operated by children or persons with mobility impairments; except under the close supervision of a competent adult who can ensure that they can operate it safely.
5. The plug must be removed from the socket when not in use, before installing or removing parts and before cleaning the machine. To unplug, grasp the plug and pull it from the electrical outlet, do not pull the power cord to unplug;
6. Do not operate the product if the power cord or plug is damaged, or if the unit malfunctions. and return the equipment to an approved service center for inspection and repair;
7. Use of non-original approved parts may result in fire, electric shock or injury;
8. Do not use the product outdoors, on moving vehicles, boats, or airplanes; do not use the product on an inclined table;
9. Do not allow the power cord to hang over the edge of a table or cabinet, or connect to any surface with a heat source, or allow the power cord to become tangled;
10. Check the bean cups for foreign objects before use;
11. Be sure to operate the product with the lid of the bean cup closed;
12. Do not place the machine on or near a gas or electric burner or in a heated oven;
13. This product is designed for home use only. Any commercial use, improper use or failure to follow instructions will invalidate the warranty.
14. Avoid contact with moving parts and do not attempt to defeat any safety interlock mechanisms.
15. This product is designed to be used only for coffee beans that have already been roasted. Do not use the appliance for any other purpose (e.g. hard seeds, herbs, nuts, etc.) as this may damage the machine;
16. All machines are rigorously inspected before leaving the factory and tested with coffee beans for actual grinding, which may result in slight traces of use or coffee residue.
17. When in use, the coffee beans should not exceed the maximum "MAX" scale of the bean box.
18. If the power supply cord is damaged, it must be replaced by the manufacturer, its service department or a professional from a similar department in order to avoid danger.
19. Be care when taking out the conical burr, emptying or cleaning the mixing room

KNOW YOUR COFFEE GRINDER



- ① Bean container lid
- ② Bean container
- ③ Bean stop plate
- ④ Lock screw
- ⑤ Coarseness ring
- ⑥ Main housing
- ⑦ Control panel
- ⑧ Outlet tube
- ⑨ Portal filter bracket
- ⑩ Start/stop switch
- ⑪ Power switch
- ⑫ Feet pad
- ⑬ Powder ground

SPECIFICATION

Model	CG Pro 2-BL
Power	300 W.
Size	Width 185 x Depth 293 x High 472 mm
Bean Capacity	550 g.
Voltage/Frequency	220-240V / ~50-60Hz.

CONTROL PANEL



FUNCTION OPERATION

• Power on:

After the machine is connected to the power supply, press the power switch button to turn it on and enter the self-test. The beep will sound once and the display will be fully lit for one second and then the default grinding time will be displayed.

• Grinding time +/-:

Grinding time adjustment range from 0-60S,



The time is selected within the range of 0~20S, each short press " + " increase 0.1S, as 0.1, 0.2, 0.3~20, hold and press " + ", the time increasing rapidly. On the contrary the same, each short press " - " decrease 0.1S, as 20, 19.9, 19.8~0, hold and press " - ", the time decreasing rapidly.


The time is selected within the range of 20~60S, each short press “+” increase 1S, as 20, 21, 22, ...60. hold and press “+”, the time increasing rapidly. On the contrary the same, each short press “-” decrease 1S, as 60, 59, 58~0, hold and press “-”, the time decreasing rapidly.

• Single cup grinding operation:



Press , the “**Single cup**”  button flashes in orange breathing light

pattern, other lights are always on, and the default time on the display is 8.0S.



Press again “**Single cup**”  button to start the grinding, the “**Single cup**”  button always on in white color and other light off on control panel ;



The grinder stop the grinding automatically after 8.0S, then “**Single cup**”  button flashes in orange breathing light pattern, other lights are always on, and the default time on the display 8.0S again. The time will be remembered when next grinding, and the time will still be remembered even when the power is unplugged.


We can also set the single cup grinding time according to your actual needs.

Press “**Single cup**”  button, the default time 8.0S on the display, can adjust the time by “+/-” buttons, the adjustment range from 0~30S. Press again the “**Single cup**”  button to start the grinding in the new setting time ; The new setting time will be remembered when next grinding, if stop the grinding when working the new setting time can not be remembered, the machine still remember last grinding time which fully finished;



• Double cup grinding operation:

Press “**Double cup**”  button, the “**Double cup**”  button flashes in orange breathing light pattern, other lights are always on, and the default time on the display is 16S.



Press again “**Double cup**”  button to start the grinding, the “**Double cup**”  button always on in white color and other light off on control panel ;



The grinder stop the grinding automatically after 16S, then “**Double cup**”  button flashes in orange breathing light pattern, other lights are always on, and the default time on the display 16S again. The time will be remembered when next grinding, and the time will still be remembered even when the power is unplugged.


We can also set the double cup grinding time according to your actual needs.

Press “**Double cup**”  button, the default time 16S on the display, can adjust the time by “+/-” buttons, the adjustment range from 0~60S. Press again the “**Double cup**”  button to start the grinding in the new setting time ; The new setting time will be remembered when next grinding, if stop the grinding when working the new setting time can not be remembered, the machine still remember last grinding time which fully finished;


• Manual grinding mode:

Press “ **Manual grinding** ”  button, the “ **Manual grinding** ”  button flashes in orange breathing light pattern, other lights are always on, and the default time on the display is 1.5S.

Press again “ **Manual grinding** ”  button to start the grinding, the “ **Manual grinding** ”  button always on in white color and other light off on control panel ;

The grinder stop the grinding automatically after 1.5S, then “ **Manual grinding** ”  button flashes in orange breathing light pattern, other lights are always on, and the default time on the display 1.5S again. The time will be remembered when next grinding, and the time will still be remembered even when the power is unplugged.

We can also set the manual grinding time according to your actual needs.

Press “ **Manual grinding** ”  button, the default time 1.5S on the display, can adjust the time by “ **+/-** ” buttons, the adjustment range from 0-3S. Press again the “ **Manual grinding** ” button to start the grinding in the new setting time ; The new setting time will be remembered when next grinding, if stop the grinding when working the new setting time can not be remembered, the machine still remember last grinding time which fully finished;

• Sleeping mode:

After finished grinding without any further operation, after 3 minutes, the beep will sound 3 times and it will enter sleep mode without any display. In sleep mode, press any key to enter standby mode.



• Memory function:

After setting the single and double cup time, the display will default to the last set time when the grinder is turned on again.

For example, the last grinding completed was a single cup time, and the default time is single cup after power on; if the last time was double cup time, the default is double cups when power is on.

The time will still be remembered even when the power is unplugged or sleep mode.

• Restore factory setting:

Press and hold both “ **Double cup** ”  and “ **Single cup** ”  buttons at the same time for 2S to restore factory settings;

• On the buzzer beep:

Press and hold both “ **+/-** ” buttons at the same time for 2S to turn off the buzzer beep sound;

HOW TO REMOVE THE COFFEE BEAN CONTAINER

1. Make sure the coffee grinder is unplugged or the On/Off switch is off.
2. Make sure there are no coffee beans in the bean container.
3. Loosen the hand-lock screw counter-clockwise until the bean box can be removed upwards.

NOTE : If there are coffee beans inside the bean container, you need to push the bean stop plate inward to the end before removing the bean box to prevent the coffee beans from leaking out.



HOW TO ASSEMBLE THE COFFEE BEAN CONTAINER

1. Make sure there is no coffee residue inside the machine's flat grinding burr.
If there is any residue, use the provided brush to clean it;
2. Insert the bean box downward into the inner hole of the upper cutter head bracket and tighten the bean box screw clockwise.

REMOVE AND ASSEMBLE THE PORTAFILTER BRACKET AND PORTAFILTER BLOCK

1. Hexagonal wrench to loosen the screws on the portafilter bracket, the height of the portafilter bracket can be adjusted up and down and tight screws, to proper height of the portafilter to better catch the coffee powder.
2. The portafilter bracket and portafilter block can be removed with the hexagonal wrench.

NOTE : In order to catch coffee powder by coffee ground jug.








COFFEE POWDER COARSENESS ADJUSTMENT

1. The grinder has multiple gears to adjust the coarseness. Turn the dial adjustment ring to adjust from fine to coarse according to the type of coffee you are brewing.
2. Rotate the coarseness ring (clockwise rotation for fine, counterclockwise rotation for coarse) to select the appropriate coarseness. Total 100 coarseness setting options.
3. When the number on the scale circle is aligned with the reference point on the top cover, it represents the coarseness setting selected.



NOTE : In order to adjust the coarseness of the coffee ground more precisely, it is recommended to rotate the bean cup at the same time to adjust the coarseness while the machine is starting up.

COFFEE GROUNDS TYPE

	Espresso	Mocca	Filter Coffee	Pour Over	French Press
Coffee Type					
Coarsenes	Fine	Slight fine	Middle coarse	Slight Coarse	Coarse
Setting	1-15	15-40	40-60	60-80	80-100

NOTE : Above info as reference, grinding coarseness should be adjusted according to actual coffee bean type and taste preference.

CLEANING

Regularly clean the grinding room and the outlet tube will prolong the life of the grinder, in addition to maintaining serving hygiene.



Take out bean container and coarseness ring, use brush to clean the blades and grinding room. Clean the outlet tube internally with the brush.

MAINTENANCE

- In order to preserve the flavor of the coffee and to avoid deterioration of the ground coffee, empty the ground coffee container after each use.
- Always unplug the grinder from the electrical outlet before cleaning.
- Never insert the power cord or the plug into water.
- Do not use strong detergents or grinding pads to clean the appliance.
- Clean the upper blade assembly with a cleaning brush.
- Carefully clean the inside of the bean container with a damp cloth.
- Place the upper grinding blade assembly in position and rotate clockwise to fit the bean cups to the desired coarseness.
- Wipe the housing of the appliance with a slightly damp cloth, then dry with a soft, lint-free cloth.

NOTE : in order to assemble the upper blade assembly and coarseness ring in position, pls make sure there is no coffee residue on the thread of coarseness ring and grinding room

TROUBLESHOOTING

Faults	Cause/Result	Solutions
No coffee ground output	Bean stop plate was not pull out	Pull the bean stop plate to the end
Not work	Not plug on or on/off switch is on off status	Plug in and turn the on/off switch on
Not work	Coarseness ring was not assembled to position	Tighten the coarseness ring
Not work	Motor PTC protection	Unplug the power cord, wait for 30mins

If you cannot find out the causes of the faults, don't disassemble the coffee grinder by yourself. Instead, contact the service center for solving the problem.

WARRANTY

We hereby warranty our Minimex Commercial Coffee Grinder model CG Pro 2-BL in a period of 1 (one) year.

Warranty Conditions

The warranty cover product defective and workmanship . Users must properly use and maintain following the instructions manual..

Warranty exceptions

We disclaims all responsibility for incidental or consequential damage caused by use of this appliance This warranty will be void if customers.

- lead to a misunderstanding of the purpose of the design, such as using product in a commercial use.
- Use the wrong way or not used as described in the instruction manual.
- no maintenance as recommended in the instruction manual.

Customer right for product warranty

The warranty is effective on the date specified in the warranty card , invoice or receipt as proof of purchase.

Determination of defective product

The company will inspect the false or defective of the product and decide that the defective of the product is in warranty or not. The decision is solely the rights of the company. If the product proved to be defected and covered by warranty, company will be responsible for parts and labor to repair and deliver the product to customers' house. Customers do not have to pay any fee.If the company considers that it must change its products to customers, but the same model of product is not available, the company will determine an appropriate version of the product to be replaced.

Returns of Product

If customer purchases to be dissatisfy. Customer could return the product within 15 days after purchasing date only if the product is completely perfect packaging and has not been used before. Customers must present proof of purchase to return the product at the store of purchase only.

Service Center

If customer need service or information, customer can contact our Minimex Service Center

Service Center : Tel. 02-493-6565, LineOA : @minimex_service

E-mail : SERVICE_minimex@penk.co.th

ENVIRONMENT FRIENDLY DISPOSAL

Please dispose of old machines in an environmentally neutral way.

Old machines contain valuable materials which should be salvaged for recycling.

Please therefore dispose of old machines via your regional collection system



MINIMEX

PROFESSIONAL

DISTRIBUTOR

จัดจำหน่ายโดย

บริษัท เพ็น เค อินเตอร์เทรดดิ้ง จำกัด

อาคาร พี.บี. ทาวเวอร์ ชั้นที่ 16 เลขที่ 1000/63-64

ถนนสุขุมวิท 71 แขวงคลองตันเหนือ เขตวัฒนา กรุงเทพฯ 10110

หมายเลขโทรศัพท์ 02-493-6565 แฟกซ์ 02-391-1141

ศูนย์บริการ minimex 02-493-6565