



สมาร์ทโฮม


# SMARTHOME

SMART SOLUTION ตอบสนองรูปแบบชีวิตแนวใหม่

## Product Manual

### Dehumidifier

### SM-DH001



Please read this manual carefully before use and keep it for future reference.

Contents

EN

Product Attribute ..... 1

Structure ..... 1

Usage instruction ..... 1 - 2

Question and Answer ..... 3

Maintenance ..... 4

Attention ..... 4

Warranty ..... 5


# Product Attribute

|                        |                            |
|------------------------|----------------------------|
| Name : Dehumidifier    | Rated power: 65W           |
| Model : SM-DH001       | Net weight: 2.3kg          |
| Rated voltage : 220 V~ | Water tank capacity : 2.3L |

# Structure



# Usage instruction



Please check all the parts are completed and undamaged before use.

## 1. Power on/off:

Press the "  " button, the dehumidifier will run at strong mode. And the 7-color light turn on ,on the displayer ,the "  " and "  " will light up and show the current humidity.

# Usage instruction

-  Strong Mode: The fan runs at the highest speed and the internal semiconductor chip runs at full power. At this time, the dehumidification performance is the best
-  Sleep Mode: The fan decelerates and the operating power drops. At this time, the noise is lowest
- A** Auto Mode: Run in strong mode, when the humidity drops below 50%, the machine will stop running to avoid excessive dehumidification

## 2. Operation mode selection :

Touch the "  " mode button to turn on the sleep mode, the icon "  " will light up and the screen brightness will decrease , Touch again the "  " mode button, the automatic mode will be turned on, the icon " **A** " will light up, and the brightness will return to normal. Then, touch "  " mode button for the third time, the icon "  " will light up

## 3. Ambient Light :

Touch the "  " light button, The color of the ambient light will be locked and it will no longer switch colors automatically, touch again to turn off the light. Then, touch this button for the third time, the ambient light will turn on again and automatically switch colors

## 4. Timing :

The timing of 0H/8H/12H/24H/36H/48H can be selected by pressing the "  " button multiple times. When you click the "  " button, the screen will firstly display the current timing setting. Then select the timing value as you want and wait for 3 seconds, the timing setting will be successful and the screen will switch to display the current humidity. If you want to cancel the timing setting, just need to adjust it to 0H.

## 5. defrost :

When the Internal semiconductor chip is frosted, the dehumidifier will automatically turn on the defrost function, and the defrost icon "  " will light up. You don't need to do anything. After the defrosting is complete, the machine will resume normal dehumidification and the icon "  " will go out.

## 6. How to empty the water tank

When the water is full, the ambient light in the water tank will flash red and three beeping sounds of "di-di-di" will be emitted from the machine. Then the machine will stop working to avoid the water leakage



( Pic.1 )



( Pic.2 )



( Pic.3 )

# Question and Answer

## 1. WHY IS IT UNDERPERFORMING ? (less water in the tank)

- Is the door or window open ? (Please close the doors and windows.)
- Is there any obstacle blocking the air inlet/outlet ?
- Is there any other equipment releasing steam indoors ?
- Is the indoor temperature too low ?

(the dehumidification capacity will be affected in a low temperature and low humidity environment. If the indoor temperature is lower than 8°C/46.4°F, the effect of dehumidification is not obvious).

## 2. Is this too noisy ?

Strong mode and auto mode have higher fan speed, so the noise is relatively higher  
If you prefer low noise, we advise you change it to sleep mode.

## 3. Abnormal sound

If the machine accidentally falls while being used, this may result. Please contact us in time and we will fix it.

## 4. The water tank or the machine body is scratched ?

This may be caused by multiple bumps of the product during transportation.

This is covered by the warranty. Please contact us and provide some photos to show us the problem. We will replace it for you.

## 5. Inaccurate display of humidity

Please understand that any humidity detection sensor has a detection distance limit, they only detect the humidity nearby. Even a distance of a few square meters, the humidity value is different. So take the humidity test result of the dehumidifier and the humidity meter in different places to compare. It is normal for the result to have errors. Even if the test places are similar, please allow a deviation of about 5% due to differences in the components of the test instrument.

## 6. Other Problem

Don't worry. We provide one year warranty for this item.

Please contact us and send us more detail about it immediately.

# Maintenance

Please make sure the product is powered off before maintenance.

1. Wipe the machine body with neutral detergent and wash the tank directly with water to ensure the service life of the machine.
2. When the machine has been cleaned, wipe to dry with a soft and dry cloth.
3. Do not spray the dehumidifier with water directly, It is forbidden to clean with detergent of acid or alkali ,otherwise it may fade or damage the dehumidifier

## Attention

1. Before using for the first time, please check whether the voltage you are using is consistent with the product nameplate requirements.
2. If the power cord is damaged, it must be replaced by a professional from the manufacturer or maintenance department in order to avoid danger.
3. DO not place the dehumidifier around the curtain or something that can be easily sucked in. Do not put it at any place with obstacle or unstable place.
4. This product is strictly prohibited to be used in an environment with flammable and explosive materials, and the use environment should not exceed 40 degrees. The best use temperature range of the dehumidifier is 15°C~40°C.
5. Please switch off and unplug the dehumidifier in case of long time not use.
6. When moving the dehumidifier, make sure that the dehumidifier is disconnected from the power supply.
7. Before use, please check if the power cord and plug are undamaged.
8. Do not twist or pull the wire,Which may cause the bad connection.
9. Don't use the dehumidifier at a lean place of angle more than 10 degree.And it cannot be used upside down.Please only use it on a flat surface.
10. Don't block the air inlet and outlet on the back to avoid poor exhaust of the dehumidifier, resulting in excessive internal temperature.
11. Please turn off the power before pulling out the plug; Please hold the plug head and pull out.
12. Do not unplug the power plug with wet hands, in case of electric shock.
13. To avoid malfunction or danger,do not use thin rods or wires to dig out something from the inside of the dehumidifier while is working.
14. Keep the dehumidifier out of children's reach.
15. This machine is not intended to be used by people (including children) who are physically, sensory, or mentally defective or lack experience and common sense (including children), unless they are given adequate care and guidance on how to use this machine by their safety officer.
16. When there are stains on the surface of the dehumidifier, use a soft cloth dampened with soap to clean it. Do not use gasoline or alcohol lamp organic solvents.
17. Don't use it in low temperature, dusty or acid-base oil lamp volatile places

# Warranty

We appreciate your feedback and will do our best to guarantee your satisfaction.

Within 1 year after your purchase, shall the product has defects, we will provide a refund or resend you a new one. Please email us with your order number or contact the seller on Amazon. Your inquiries will be taken care of as soon as possible.

This warranty does not cover normal wear of product and damage caused by misoperation of buyers.

This warranty only cover orders from authorized Amazon Store and our official website. We are not responsible for any purchases from other distribution channels.



SMARTHOME


สมาร์ทโฮม

SMART SOLUTION ตอบสนองรูปแบบชีวิตแนวใหม่

# คู่มือผลิตภัณฑ์

## เครื่องลดความชื้น

### SM-DH001



โปรดอ่านคู่มือนี้อย่างระมัดระวังก่อนใช้งานและเก็บไว้ใช้อ้างอิงในอนาคต

# เนื้อหา

# ไทย

|                             |       |
|-----------------------------|-------|
| คุณสมบัติของผลิตภัณฑ์ ..... | 1     |
| โครงสร้าง .....             | 1     |
| คำแนะนำในการใช้งาน .....    | 1 - 2 |
| คำถามและคำตอบ .....         | 3     |
| การบำรุงรักษา .....         | 4     |
| คำเตือน .....               | 4     |
| การรับประกัน .....          | 5     |


# คุณสมบัติของผลิตภัณฑ์

|                          |                      |
|--------------------------|----------------------|
| ชื่อ : เครื่องลดความชื้น | กำลังไฟฟ้า : 65W     |
| รุ่น : SM-DH001          | น้ำหนัก : 2.3 kg.    |
| แรงดันไฟฟ้า : 220V~      | ความจุถังน้ำ : 2.3L. |

## โครงสร้าง



## คำแนะนำในการใช้งาน



โปรดตรวจสอบชิ้นส่วนทั้งหมดเสร็จสมบูรณ์และไม่เสียหายก่อนใช้งาน

### 1.สวิตช์ เปิด / ปิด

กดที่ " ( ) " ปุ่ม, เครื่องทำลดความชื้นจะทำงานอยู่ในโหมดที่แข็งแรงและแสง 7 สี  
เปิดบนจอแสดงผล " " และ " " จะสว่างขึ้นและแสดงความชื้นในขณะนั้น

# คำแนะนำในการใช้งาน



โหมดแรง: พัดลมวิ่งด้วยความเร็วสูงสุดและชิปเซมิคอนดักเตอร์ภายในทำงานเต็มกำลังในเวลานี้ ประสิทธิภาพการลดความชื้นเป็นสิ่งที่ดีที่สุด



โหมดการนอนหลับ: พัดลมชะลอตัวและกำลังการทำงานลดลง ในเวลานี้เสียงรบกวนต่ำที่สุด



โหมดอัตโนมัติ: ทำงานในโหมดแรงเมื่อความชื้นลดลงต่ำกว่า 50% เครื่องจะหยุดวิ่งเพื่อหลีกเลี่ยงการลดความชื้นมากเกินไป

## 2. การเลือกโหมดการทำงาน:

แตะที่ปุ่ม "☼" เพื่อปิดโหมดการนอนหลับ ไอคอน "☼" จะสว่างขึ้นและความสว่างของหน้าจอจะลดลง

แตะอีกครั้งที่ปุ่ม "☼" โหมด อัตโนมัติ

โหมดจะถูกเปิด ไอคอน "A" จะสว่างขึ้น และความสว่างจะกลับมาเป็นปกติ

จากนั้นแตะที่ปุ่ม "☼" โหมดเป็นครั้งที่สาม "☼" จะสว่างขึ้น

## 3. แสงแวดล้อม:

แตะที่ปุ่ม "☼" สิ่งแวดล้อมจะถูกเลือกและจะไม่

สลับสีโดยอัตโนมัตินานขึ้น เตะอีกครั้งเพื่อปิดไฟในแตะที่ปุ่มนี้

เป็นครั้งที่สามที่ไฟแวดล้อมจะปิดอีกครั้งและเปลี่ยนสีโดยอัตโนมัติ

## 4. เวลา:

สามารถเลือกเวลาของ OH/8H/12H/24H/36H/48H ได้โดยการกดปุ่ม "⌚"

หลายครั้ง เมื่อคุณกดปุ่ม "⌚" หน้าจอจะแสดงผลอย่างรวดเร็ว

การตั้งเวลา. จากนั้นเลือกค่าการจับเวลาตามที่คุณต้องการและรอ 3 วินาที, การจับเวลา

การตั้งค่าสำเร็จ และหน้าจอจะสลับเพื่อแสดงความชื้นปัจจุบัน หากคุณ

ต้องการยกเลิกการตั้งค่าเวลา แค่ต้องปรับเป็น OH

## 5. การละลายน้ำแข็ง:

เมื่อชิปเซมิคอนดักเตอร์ภายในถูกแช่แข็ง เครื่องกำจัดความชื้นจะเปิดโดยอัตโนมัติ

ฟังก์ชันการละลายน้ำแข็ง และไอคอนการละลายน้ำแข็ง "❄" จะสว่างขึ้น คุณไม่จำเป็นต้องทำอะไรเลย

หลังจากการละลายน้ำแข็งเสร็จสิ้น เครื่องจะดำเนินการล้างความชื้นตามปกติและ

ไอคอน "❄" จะดับไป

## 6. วิธีการระบายน้ำออกจากถังน้ำ

เมื่อน้ำเต็ม ไพรอบ ๆ ในถังน้ำจะกะพริบเป็นสีแดง และเครื่องจะส่งเสียงบีบสามครั้ง

จากนั้นเครื่องจะหยุดทำงานเพื่อหลีกเลี่ยงการรั่วซึมของน้ำ



( Pic.1 )



( Pic.2 )



( Pic.3 )

# คำแนะนำในการใช้งาน



โหมดแรง: พัฒมวังด้วยความเร็วสูงสุดและชิปไมคอนตักเตอร์ภายในทำงานเต็มกำลังในเวลานี้ ประสิทธิภาพการลดความชื้นเป็นสิ่งที่ดีที่สุด



โหมดการนอนหลับ: พัฒมชะลอตัวและกำลังการทำงานลดลง ในเวลานี้เสียงรบกวนต่ำที่สุด



โหมดอัตโนมัติ: ทำงานในโหมดแรงเมื่อความชื้นลดลงต่ำกว่า 50% เครื่องจะหยุดวิ่งเพื่อหลีกเลี่ยงการลดความชื้นมากเกินไป

## 2. การเลือกโหมดการทำงาน:

แตะที่ปุ่ม " " เพื่อปิดโหมดการนอนหลับ ไอคอน " " จะสว่างขึ้นและความสว่างของหน้าจอจะลดลง

แตะอีกครั้งที่ปุ่ม " " โหมด อัตโนมัติ

โหมดจะถูกเปิด ไอคอน " **A** " จะสว่างขึ้น และความสว่างจะกลับมาเป็นปกติ

จากนั้นแตะที่ปุ่ม " " โหมดเป็นครั้งที่สาม " " จะสว่างขึ้น

## 3. แสงแวดล้อม:

แตะที่ปุ่ม " " สิ่งแวดล้อมจะถูกเลือกและจะไม่

สลับสัโดยอัตโนมัติบนนั้น แตะอีกครั้งเพื่อปิดไฟบนแตะที่ปุ่มนี้

เป็นครั้งที่สามที่ไฟแวดล้อมจะปิดอีกครั้งและเปลี่ยนสัโดยอัตโนมัติ

## 4. เวลา:

สามารถเลือกเวลาของ OH/8H/12H/24H/36H/48H ได้โดยการกดปุ่ม " " "

หลายครั้ง เมื่อคุณกดปุ่ม " " หน้าจอจะแสดงผลอย่างรวดเร็ว

การตั้งเวลา. จากนั้นเลือกค่าการจับเวลาตามที่คุณต้องการและรอ 3 วินาที, การจับเวลา

การตั้งค่าจะสำเร็จ และหน้าจอจะสลับเพื่อแสดงความชื้นปัจจุบัน หากคุณ

ต้องการยกเลิกการตั้งค่าเวลา แค่ต้องปรับเป็น OH

## 5. การละลายน้ำแข็ง:

เมื่อชิปไมคอนตักเตอร์ภายในถูกแช่แข็ง เครื่องกำจัดความชื้นจะเปิดโดยอัตโนมัติ

ฟังก์ชันการละลายน้ำแข็ง และไอคอนการละลายน้ำแข็ง " " จะสว่างขึ้น คุณไม่จำเป็นต้องทำอะไรเลย

หลังจากการละลายน้ำแข็งเสร็จสิ้น เครื่องจะดำเนินการล้างความชื้นตามปกติและ

ไอคอน " " จะดับไป

## 6. วิธีการระบายน้ำออกจากถังน้ำ

เมื่อน้ำเต็ม ไพรอบ ๆ ในถังน้ำจะกะพริบเป็นสีแดง และเครื่องจะส่งเสียงบีบสามครั้ง

จากนั้นเครื่องจะหยุดทำงานเพื่อหลีกเลี่ยงการรั่วซึมของน้ำ



( Pic.1 )



( Pic.2 )



( Pic.3 )

# การบำรุงรักษา

โปรดตรวจสอบให้แน่ใจว่าผลิตภัณฑ์ถูกปิดก่อนการบำรุงรักษา

1. เช็ดตัวเครื่องด้วยน้ำยาซักฟอกที่เป็นกลางและล้างโดยตรงด้วยน้ำเพื่อ ยึดอายุการใช้งานของเครื่อง
2. เมื่อทำความสะอาดเครื่องแล้ว ให้เช็ดให้แห้งด้วยผ้าที่นุ่มและแห้ง
3. ห้ามฉีดพ่นน้ำยาล้างความชื้นด้วยน้ำโดยตรง ห้ามทำความสะอาดด้วยน้ำยาซักฟอกของกรดหรือด่าง ตัวเครื่องสีอาจจางลงหรือทำลายเครื่องกำจัดความชื้น

## คำเตือน

1. ก่อนใช้ครั้งแรก โปรดตรวจสอบว่าแรงดันไฟฟ้าที่คุณใช้สอดคล้องกันหรือไม่ ด้วยข้อกำหนดป้ายชื่อผลิตภัณฑ์
2. หากสายไฟเสียหาย ต้องเปลี่ยนด้วยช่างมืออาชีพจากผู้ผลิต หรือแผนกซ่อมบำรุงเพื่อหลีกเลี่ยงอันตราย
3. อย่าวางเครื่องกำจัดความชื้นใกล้ผ้า่านหรือสิ่งที่สามารถดูดเข้าได้ง่าย อย่างวุ่นในสถานที่ใด ๆ ที่มีอุปสรรคหรือสถานที่ที่ไม่มั่นคง
4. ผลิตภัณฑ์นี้ห้ามใช้ในสภาพแวดล้อมที่มีการเผาไหม้และระเบิดอย่างรวดเร็ว วัสดุและสภาพแวดล้อมการใช้งานไม่ควรเกิน 40 องศา อุณหภูมิที่ใช้ได้ดีที่สุดของเครื่องกำจัดความชื้นคือ 159C~409C
5. กรุณาปิดและถอดปลั๊กเครื่องกำจัดความชื้นในกรณีที่ไม่ได้ใช้งานนาน
6. เมื่อย้ายเครื่องกำจัดความชื้น ตรวจสอบให้แน่ใจว่าเครื่องกำจัดความชื้นถูกตัดการเชื่อมต่อจากแหล่งจ่ายไฟ.
7. ก่อนใช้งาน โปรดตรวจสอบว่าสายไฟและปลั๊กไฟว่าเสียหายหรือไม่
8. อย่าบิดหรือดึงสายไฟซึ่งอาจทำให้เกิดการเชื่อมต่อที่ไม่ดี
9. อย่าใช้เครื่องกำจัดความชื้นในที่ราบของนูนมากกว่า 10 องศาและมันเป็นไปไม่ได้ ไขกลับหัว กรุณาใช้บนพื้นผิวเรียบเท่านั้น
10. อย่าปิดกั้นช่องระบายอากาศและช่องระบายอากาศด้านหลังเพื่อหลีกเลี่ยงการระบายความร้อนที่ไม่ดีของเครื่องกำจัดความชื้น ส่งผลให้มีอุณหภูมิภายในมากเกินไป
11. กรุณาปิดไฟก่อนดึงปลั๊กออก กรุณาดึงหัวปลั๊กและดึงออก
12. อย่าถอดปลั๊กไฟด้วยมือเปียก เดือดไฟฟ้าช็อตเป็นอันตราย
13. เพื่อหลีกเลี่ยงการทำงานผิดปกติหรืออันตราย ห้ามใช้แท่งหรือลวดบางๆ ขุดแ่งสิ่งของบางอย่างออกจากภายในเครื่องลดความชื้นในขณะที่ยังเครื่องกำลังทำงาน
14. เก็บเครื่องกำจัดความชื้นให้พ้นมือเด็ก
15. เครื่องนี้ไม่ได้ตั้งใจให้ใช้โดยเด็ก! รวมไปถึงคนที่มีร่างกายไม่แข็งแรง ประสาทสัมผัส หรือบกพร่องทางจิตใจ หรือขาดประสบการณ์และสามัญสำนึก (รวมถึงเด็ก) เว้นแต่พวกเขาได้รับการดูแลและคำแนะนำที่เพียงพอเกี่ยวกับวิธีการใช้เครื่องนี้จนพวกเขา (ผู้ปกครอง)
16. เมื่อมีรอยเปื้อนบนพื้นผิวของ เครื่องกำจัดความชื้น ให้ใช้ผ้านุ่มซับด้วย น้ำยาทำความสะอาดเพื่อทำความสะอาดมัน ห้ามใช้ตัวทำลายอินทรีย์ เช่น น้ำเบ็นซินหรือแอลกอฮอล์
17. อย่าใช้ในอุณหภูมิต่ำ ฝุ่นละอองหรือกรด-เบสจะกึ่งน้ำมันที่ระเหย

# การรับประกัน

## การรับประกัน

เราขอขอบคุณสำหรับความคิดเห็นของคุณและจะพยายามอย่างเต็มที่เพื่อรับประกันความพึงพอใจของคุณภายในสามปีหลังจากการซื้อของคุณ ผลิตภัณฑ์ที่มีข้อบกพร่อง เราจะบริการซ่อมส่งอันใหม่ให้คุณ กรุณาส่งอีเมลถึงเราพร้อมหมายเลขคำสั่งซื้อของคุณหรือติดต่อผู้ขายคำถามของคุณจะได้รับการดูแลโดยเร็วที่สุดเท่าที่เป็นไปได้

การรับประกันนี้ไม่ครอบคลุมการสึกหรอปกติของผลิตภัณฑ์และที่เกิดจากการใช้งานผิดพลาดของผู้ซื้อ

การรับประกันนี้ครอบคลุมเฉพาะคำสั่งจากร้านค้าที่ได้รับอนุญาตและเว็บไซต์อย่างเป็นทางการของเรา พวกเราไม่รับผิดชอบต่อการซื้อสินค้าจากช่องทางทางการจัดจำหน่ายอื่น ๆ